

- Estate agency
- Property letting
- Independent property advice

A personal approach to professional property services.

What to do if your Smoke Detector or Carbon Monoxide Detector is beeping

If your smoke detector or carbon monoxide detector is beeping constantly then you may need to change the battery. They should also be tested regularly by pushing and releasing the button. This is very important for your safety and could save your life in the event of a fire.

Candles are a common cause of fire in residential homes and should never be left unattended. As a reminder, the use of Candles, Smoking and Flammable Items in the property are all prohibited under the terms of all SouthSide Property Lease Agreements. The article below is a prime example of the dangers of candles and not having a working fire alarm <http://www.theedinburghreporter.co.uk/2014/09/unattended-candlecauses-fire-in-morningside-flat/>